

**FWS-2350**

Desktop

Network Appliance Platform

CompactFlash™ Socket

6 LAN Ports

2 USB2.0, 1 COM for Console

## Copyright Notice

This document is copyrighted, 2014. All rights are reserved. The original manufacturer reserves the right to make improvements to the products described in this manual at any time without notice.

No part of this manual may be reproduced, copied, translated, or transmitted in any form or by any means without the prior written permission of the original manufacturer. Information provided in this manual is intended to be accurate and reliable. However, the original manufacturer assumes no responsibility for its use, or for any infringements upon the rights of third parties that may result from its use.

The material in this document is for product information only and is subject to change without notice. While reasonable efforts have been made in the preparation of this document to assure its accuracy, AAeon assumes no liabilities resulting from errors or omissions in this document, or from the use of the information contained herein. AAeon reserves the right to make changes in the product design without notice to its users.

## Acknowledgments

All other products' name or trademarks are properties of their respective owners.

- Intel<sup>®</sup> and Atom<sup>™</sup> are trademarks of Intel<sup>®</sup> Corporation.
- AML is a trademark of American Megatrends Inc.
- CompactFlash<sup>™</sup> is a trademark of the Compact Flash Association.
- Microsoft Windows<sup>®</sup> is a registered trademark of Microsoft Corp.

All other product names or trademarks are properties of their respective owners.

## Caution

There is a danger of explosion if the battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions and your local government's recycling or disposal directives.

***Attention:***

Il y a un risque d'explosion si la batterie est remplacée de façon incorrecte. Ne la remplacer qu'avec le même modèle ou équivalent recommandé par le constructeur. Recycler les batteries usées en accord avec les instructions du fabricant et les directives gouvernementales de recyclage.

## Packing List

Before you begin installing your card, please make sure that the following materials have been shipped:

- FWS-2350
- CD-ROM for manual (in PDF format) and drivers

If any of these items should be missing or damaged, please contact your distributor or sales representative immediately.

# Contents

## Chapter 1 General Information

1.1 Introduction.....	1-2
1.2 Features .....	1-3
1.3 Specifications .....	1-4
1.4 General System Information .....	1-7

## Chapter 2 Quick Installation Guide

2.1 Safety Precautions .....	2-2
2.2 Location of Connectors of Main Board.....	2-3
2.3 Mechanical Drawing of Main Board .....	2-5
2.4 List of Jumpers .....	2-7
2.5 List of Connectors .....	2-7
2.6 Setting Jumpers .....	2-9
2.7 CF POWER Selection (JP1) .....	2-10
2.8 Auto PWRBTN Selection (JP2).....	2-10
2.9 CMOS Setting Selection (CMOS1) .....	2-10
2.10 LAN LED Connector (CN4).....	2-10
2.11 Front Panel Connector (CN5) .....	2-11
2.12 LAN LED Connector (CN6).....	2-11
2.13 SATA Power Connector (CN8.9.10.11) .....	2-12
2.14 4-pin ATX Power Connector (CN16).....	2-12
2.15 Pin Header (USB1) .....	2-12
2.16 Console Port (CON1) .....	2-12

2.17 Hard Disk Installation .....	2-13
2.18 VGA Card Installation .....	2-19

## Chapter 3 AMI BIOS Setup

3.1 System Test and Initialization .....	3-2
3.2 AMI BIOS Setup .....	3-3

## Chapter 4 Driver Installation

4.1 Installation .....	4-3
------------------------	-----

## Appendix A Programming the Watchdog Timer

A.1 Watchdog Timer Initial Program .....	A-2
--	-----

## Appendix B I/O Information

B.1 I/O Address Map .....	B-2
B.2 Memory Address Map .....	B-3
B.3 IRQ Mapping Chart .....	B-4

## Appendix C Standard LAN Bypass Platform Settings

C.1 Status LED .....	C-2
C.2 Status LED Configuration .....	C-2
C.3 Status LED Sample Code .....	C-8
C.4 LAN Bypass .....	C-5
C.5 LAN Bypass Configuration .....	C-5
C.6 LAN Bypass Sample Code .....	C-6
C.7 Software Reset Button .....	C-8
C.8 Software Reset Button Configuration .....	C-8
C.9 Software Reset Button Sample Code .....	C-8

Chapter

1

**General  
Information**

## 1.1 Introduction

---

FWS-2350 adopts the Intel® Dual Core Atom™ C2358 1.7 GHz/ Quad Core Atom™ C2558 2.4 GHz. The system memory features DDR3 Long-DIMM socket, ECC or non-ECC SDRAM up to 16GB. It deploys 6x Gigabit Ethernet LAN ports with 2 pairs of LAN bypass function. The condensed appearance of the FWS-2350 features desktop form factor that fits nicely into a space-limited environment.

This compact FWS-2350 is equipped with CF socket x1 and Mini-Card socket x1 with SIM socket. In addition, it offers flexible expansion with network products and features additional Mini-Card socket x1 (optional), USB2.0 ports x2 and RJ-45 console port x1. The console port deploys console re-direction that increases the network security via remote control. All of these designs provide for a more user-friendly solution.

## 1.2 Features

---

- Built-in Gigabit Ethernet x 6
- Dual Core Intel® Atom™ C2358 1.7 GHz/ Quad Core Atom™ C2558 2.4 GHz
- Supports QuickAssist Crypto Acceleration
- DDR3 Long-DIMM socket, supports up to 16GB ECC or non-ECC SDRAM
- Built-in Intel® I211 LAN Controller and Marvell PHY 88E1543
- System cooling fan x 1
- Supports 2 pairs of LAN bypass function
- Compact desktop design

### 1.3 Specifications

---

#### *System*

<b>Form Factor</b>	Desktop 6-ports Network Appliance
<b>Processor</b>	Dual Core Intel® Atom™ C2358 1.7 GHz Processor Quad Core Intel® Atom™ C2558 2.4 GHz Processor
<b>System Memory</b>	DDR3 Long-DIMM slot Dual-channel DDR3/DDR3L 1333/1600MHz, ECC or non-ECC SDRAM up to 16GB
<b>Ethernet</b>	Intel® I211 x 2, Marvell 88E1543 x 1
<b>BIOS</b>	AMI BIOS
<b>SSD</b>	CF x 1
<b>Serial ATA</b>	Onboard SATA3 port x 1 Onboard SATA3 port x 1 (Optional) Onboard SATA2 port x 2 (Optional)
<b>Expansion Interface</b>	Mini-Card socket (Full Size) with SIM socket x 1 Mini-Card socket (Full Size) x 1 (Optional) CF Socket x 1
<b>Watchdog Timer</b>	1~255 steps by software programming
<b>RTC</b>	Internal RTC
<b>Storage</b>	Type 2 CompactFlash™ socket x 1 (default) or CFast™ socket x 1 (optional),

	2.5" HDD Bay x 1
<b>System Fan</b>	4 cm ball bearing fan
<b>Front I/O Panel</b>	Power LED x 1, Status LED x 1, HDD Active LED x 1, LAN LED x 12, Bypass LED x 2
<b>Rear I/O Panel</b>	USB2.0 port x 2, RJ-45 x 6, RJ-45 console x 1, 12V DC power input x 1, Software Reset Switch x 1, VGA internal box header (optional with add-on VGA)
<b>Color</b>	Black
<b>Power Supply</b>	12V DC power in connector/ 60W power adapter x 1, 4-pin DC power out connector for HDD (optional)
<b>Dimension</b>	10.24"(W) x 1.73"(H) x 7.00"(D) (260mm x 44mm x 178mm)

## *I/O*




<b>Serial Port</b>	RJ-45 console x 1
<b>Keyboard &amp; Mouse</b>	Reserved pin header
<b>USB</b>	USB2.0 Type A on I/O side x 2

## *Environment*

<b>Operating Temperature</b>	32°F~104°F (0°C ~40°C)
------------------------------	------------------------

<b>Storage Temperature</b>	-4°F~104°F (-20°C ~60°C)
<b>Operating Humidity</b>	10%~80% relative humidity, non-condensing
<b>Storage Humidity</b>	10%~80% @ 40°C, non-condensing
<b>Vibration</b>	0.5g rms/5~500Hz/ operation (2.5" hard disk drive) 1.5g rms/5~500Hz/ non-operation
<b>Shock</b>	10G peak acceleration (11m sec. duration), operation 20G peak acceleration (11m sec. duration), non operation

## 1.4 General System Information



Chapter

2

**Quick  
Installation  
Guide**

## 2.1 Safety Precautions

---

The installation is intended for technically qualified personnel who have experience installing and configuring system boards.

The equipment can be installed in a restricted access location (RAL) only.

A restricted access location is a site location for equipment where the following criteria apply:

01. Access can only be gained by service persons or by users who have been trained on the restrictions and the precautions for this specific site.

02. Access is by means of at least one of the following, special tool, lock and key, or other means of security, and is controlled by the authority responsible for the location.

### Safety Precautions:

#### **Warning!**




*Always completely disconnect the power cord from your board whenever you are working on it. Do not make connections while the power is on, because a sudden rush of power can damage sensitive electronic components.*

#### **Caution!**





*Always ground yourself to remove any static charge before touching the board. Modern electronic devices are very sensitive to static electric charges. Use a grounding wrist strap at all times. Place all electronic components on a static-dissipative surface or in a static-shielded bag when they are not in the chassis*

## 2.2 Location of Connectors of Main Board




\*Memory assembly priority: (1) DIMM1 (2) DIMM2







LEDs on Front Panel of FWS-2350




Connectors on Rear Panel of FWS-2350



### 2.3 Mechanical Drawing of Main Board





## 2.4 List of Jumpers

---

The board has a number of jumpers that allow you to configure your system to suit your application.

The table below shows the function of each of the board's jumpers:

<b>Label</b>	<b>Function</b>
CMOS1	CMOS Setting Selection
JP2	Auto PWRBTN Selection
JP1	CF POWER Selection

## 2.5 List of Connectors

---

The board has a number of connectors that allow you to configure your system to suit your application. The table below shows the function of each board's connectors:

<b>Label</b>	<b>Function</b>
DIMM1	DDR3 U-DIMM SOCKET
DIMM2	DDR3 U-DIMM SOCKET
CN16	4P ATX POWER SUPPLY INPUT
CN18	DC 12V IN JACK
CPU_FAN1	4P SMART FAN
SYS_FAN1	4P SMART FAN
SYS_FAN2	4P SMART FAN
CN7	KB/MS
COM1	COM PORT
CON1	console PORT
USB1	USB 2.0 *1
USB2	USB 2.0 *2
CN5	Front Panel Pinheader

---

SATA6G_1/2	SATA3 INTERFACE
SATA3G_1/2	SATA2 INTERFACE
CN8.9.10.11	SATA POWER
CN13	Mini PCI-E socket
CN4/CN6	LAN LED Pinheader


---

## 2.6 Setting Jumpers

---

You configure your card to match the needs of your application by setting jumpers. A jumper is the simplest kind of electric switch. It consists of two metal pins and a small metal clip (often protected by a plastic cover) that slides over the pins to connect them. To “close” a jumper you connect the pins with the clip.

To “open” a jumper you remove the clip. Sometimes a jumper will have three pins, labeled 1, 2 and 3. In this case you would connect either pins 1 and 2 or 2 and 3.



A pair of needle-nose pliers may be helpful when working with jumpers.

If you have any doubts about the best hardware configuration for your application, contact your local distributor or sales representative before you make any change.

Generally, you simply need a standard cable to make most connections.

## 2.7 CF POWER Selection (JP1)

---

JP1	Function
1-2	5V
2-3	3.3V (Default)

---

## 2.8 Auto PWRBTN Selection (JP2)

---

JP2	Function
1-2	Don't use Auto PWRBTN (Default)
2-3	Use Auto PWRBTN

---

## 2.9 CMOS Setting Selection (CMOS1)

---

CMOS1	Function
1-2	Normal (Default)
2-3	Clear CMOS

---

## 2.10 LAN LED Connector (CN4)

---

Pin	Signal	Pin	Signal
1	L1_ACT#	2	L1_1K
3	L1_ACT	4	L1_100
5	L2_ACT#	6	L2_1K
7	L2_ACT	8	L2_100
9	L3_ACT#	10	L3_1K
11	L3_ACT	12	L3_100
13	L4_ACT#	14	L4_1K

---

15	L4_ACT	16	L4_100
17	L5_ACT#	18	L5_1K
19	L5_ACT	20	L5_100
21	L6_ACT#	22	L6_1K
23	L6_ACT	24	L6_100

### 2.11 Front Panel Connector (CN5)

Pin	Signal	Pin	Signal
1	Power On Button (-)	2	Power On Button (+)
3	HDD LED(-)	4	HDD LED(+)
5	External Speaker (-)	6	External Speaker (+)
7	Power LED (-)	8	Power LED (+)
9	Reset Switch (-)	10	Reset Switch (+)

### 2.12 LAN LED Connector (CN6)

Pin	Signal	Pin	Signal
1	L7_ACT#	2	L7_1K
3	L7_ACT	4	L7_100
5	L8_ACT#	6	L8_1K
7	L8_ACT	8	L8_100
9	BPLED1-	10	BPLED1+
11	BPLED2-	12	BPLED2+
13	STLED-RED	14	STLED-GRN

### 2.13 SATA Power Connector (CN8.9.10.11)

Pin	Signal	Pin	Signal
1	+12V	2	GND
3	GND	4	+5V

### 2.14 4-pin ATX Power Connector (CN16)

Pin	Signal	Pin	Signal
1	GND	2	GND
3	+12V	4	+12V

### 2.15 Pin Header (USB1)

Pin	Signal	Pin	Signal
1	+5V		
2	USBD1-		
3	USBD1+		
4	GND		
5	GND		

### 2.16 Console Port (CON1)

Pin	Signal	Pin	Signal
1	RTS1X	2	DTR1X
3	SOUT1X	4	GND
5	GND	6	SIN1X
7	DSR1X	8	CTS1X

## 2.17 Hard Disk Installation

---

Step1: Remove the cover



Step 2: Slide right to remove casing



Step 3: Turn screw clockwise to open HDD casing



Step 4: Attach all four screws of the casing to the HDD



Step 5: Attach the SATA and Power cable to the HDD



Step 6: Place the HDD onto the HDD bracket of the casing



Step 7: Cover up the casing



Step 8: Turn the screw counter-clockwise to secure the casing



Step 9: Connect the SATA and Power cables to the mainboard



Step 10: Place the casing into the chassis, slide right to secure



Step 11: Close and secure the cover



## 2.18 VGA Card Installation

---

Step 1: Remove the cover



Step 2: Insert the VGA Card into Mini-PCle slot



Step 3: Secure the card by tightening the screws



Step 4: Connect your VGA device. Both screws must be secured for the connector to function properly



Step 5: Close and secure the cover



**China RoHS Requirements**  
**产品中有毒有害物质或元素名称及含量**  
**AAEON Boxer/ Industrial System**

部件名称	有毒有害物质或元素					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
印刷电路板 及其电子组件	×	○	○	○	○	○
外部信号 连接器及线材	×	○	○	○	○	○
外壳	×	○	○	○	○	○
中央处理器 与内存	×	○	○	○	○	○
硬盘	×	○	○	○	○	○
电源	×	○	○	○	○	○
<p><b>O:</b> 表示该有毒有害物质在该部件所有均质材料中的含量均在  <b>SJ/T 11363-2006</b> 标准规定的限量要求以下。</p> <p><b>X:</b> 表示该有毒有害物质至少在该部件的某一均质材料中的含量超出  <b>SJ/T 11363-2006</b> 标准规定的限量要求。</p> <p><b>备注:</b>            一、此产品所标示之环保使用期限, 系指在一般正常使用状况下。            二、上述部件物质中央处理器、内存、硬盘、电源为选购品。</p>						

Chapter

3

**AMI  
BIOS Setup**

### 3.1 System Test and Initialization

---

These routines test and initialize board hardware. If the routines encounter an error during the tests, you will either hear a few short beeps or see an error message on the screen. There are two kinds of errors: fatal and non-fatal. The system can usually continue the boot up sequence with non-fatal errors.

#### System configuration verification

These routines check the current system configuration stored in the CMOS memory and BIOS NVRAM. If system configuration is not found or system configuration data error is detected, system will load optimized default and re-boot with this default system configuration automatically.

There are four situations in which you will need to setup system configuration:

1. You are starting your system for the first time
2. You have changed the hardware attached to your system
3. The system configuration reset by Clear-CMOS jumper
4. The CMOS memory has lost power and the configuration information has been erased.

The FWS-2350 CMOS memory has an integral lithium battery backup for data retention. However, you will need to replace the complete unit when it finally runs down.

## 3.2 AMI BIOS Setup

---

AMI BIOS ROM has a built-in Setup program that allows users to modify the basic system configuration. This type of information is stored in battery-backed CMOS RAM and BIOS NVRAM so that it retains the Setup information when the power is turned off.

### Entering Setup

Power on the computer then press <Del> or <F2> immediately. This will allow you to enter Setup.

### Main

Set the date, use tab to switch between date elements.

### Advanced

Enable/disable boot option for legacy network devices.

### Chipset

Host bridge parameters.

### Boot

Enables/disables quiet boot option.

### Security

Set setup administrator password.

### Save & Exit


Exit system setup after saving the changes.

## Setup Menu


### Setup submenu: Main



## Setup submenu: Advanced




## USB Configuration




### Options summary:

Legacy USB Support	Enabled	Optimal Default, Failsafe Default
	Disabled	
	Auto	
Enables BIOS Support for Legacy USB Support. When enabled, USB can be functional in legacy environment like DOS. AUTO option disables legacy support if no USB devices are connected		
Device Name (Emulation Type)	Auto	Optimal Default, Failsafe Default
	Floppy	
	Forced FDD	
	Hard Disk	
	CDROM	
If Auto. USB devices less than 530MB will be emulated as Floppy and remaining as Floppy and remaining as hard drive. Forced FDD option can be used to force a HDD formatted drive to boot as FDD(Ex. ZIP drive)		

## Super IO Configuration



## Serial Port 1 Configuration



### Options summary:

Serial Port	Disabled	Optimal Default, Failsafe Default
	Enabled	
Allows BIOS to En/Disable correspond serial port.		
Change Settings	Auto	Optimal Default, Failsafe Default
	IO=3F8h; IRQ=4;	
	IO=3F8h;	
	IRQ=3,4,5,6,7,9,10,11,12;	
	IO=2F8h;	
	IRQ=3,4,5,6,7,9,10,11,12;	
	IO=3E8h;	
	IRQ=3,4,5,6,7,9,10,11,12;	
	IO=2E8h;	
Allows BIOS to Select Serial Port resource.		

## Serial Port 2 Configuration

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.

Advanced

Serial Port 2 Configuration		Enable or Disable Serial Port (COM)
Serial Port	[Enabled]	⇧⇩: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
Device Settings	IO=2F8h; IRQ=3;	
Change Settings	[Auto]	

Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.

### Options summary:

Serial Port	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="padding: 2px;">Disabled</td> <td rowspan="2" style="padding: 2px;">Optimal Default, Failsafe Default</td> </tr> <tr> <td style="padding: 2px;">Enabled</td> </tr> </table>	Disabled	Optimal Default, Failsafe Default	Enabled									
Disabled	Optimal Default, Failsafe Default												
Enabled													
Allows BIOS to En/Disable correspond serial port.													
Change Settings	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="padding: 2px;">Auto</td> <td rowspan="6" style="padding: 2px;">Optimal Default, Failsafe Default</td> </tr> <tr> <td style="padding: 2px;">IO=2F8h; IRQ=3;</td> </tr> <tr> <td style="padding: 2px;">IO=3F8h;</td> </tr> <tr> <td style="padding: 2px;">IRQ=3,4,5,6,7,9,10,11,12;</td> </tr> <tr> <td style="padding: 2px;">IO=2F8h;</td> </tr> <tr> <td style="padding: 2px;">IRQ=3,4,5,6,7,9,10,11,12;</td> </tr> <tr> <td style="padding: 2px;">IO=3E8h;</td> </tr> <tr> <td style="padding: 2px;">IRQ=3,4,5,6,7,9,10,11,12;</td> </tr> <tr> <td style="padding: 2px;">IO=2E8h;</td> </tr> <tr> <td style="padding: 2px;">IRQ=3,4,5,6,7,9,10,11,12;</td> </tr> </table>	Auto	Optimal Default, Failsafe Default	IO=2F8h; IRQ=3;	IO=3F8h;	IRQ=3,4,5,6,7,9,10,11,12;	IO=2F8h;	IRQ=3,4,5,6,7,9,10,11,12;	IO=3E8h;	IRQ=3,4,5,6,7,9,10,11,12;	IO=2E8h;	IRQ=3,4,5,6,7,9,10,11,12;	
Auto	Optimal Default, Failsafe Default												
IO=2F8h; IRQ=3;													
IO=3F8h;													
IRQ=3,4,5,6,7,9,10,11,12;													
IO=2F8h;													
IRQ=3,4,5,6,7,9,10,11,12;													
IO=3E8h;													
IRQ=3,4,5,6,7,9,10,11,12;													
IO=2E8h;													
IRQ=3,4,5,6,7,9,10,11,12;													
Allows BIOS to Select Serial Port resource.													

## H/W Monitor

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.


Advanced

Pc Health Status	
CPU temperature	: +46 %
System temperature	: +34 %
Fan1 Speed	: N/A
Fan2 Speed	: N/A
VDDRE	: +0.852 V
VMEM	: +1.512 V
+12V	: +12.000 V
+5V	: +4.979 V
5VSB	: +4.979 V
VBAT	: +3.000 V


←+: Select Screen  
↑↓: Select Item  
Enter: Select  
+/-: Change Opt.  
F1: General Help  
F2: Previous Values  
F3: Optimized Defaults  
F4: Save & Exit  
ESC: Exit

Version 2.16.1242, Copyright (C) 2013 American Megatrends, Inc.

## Power Management




### S5 RTC Wake Settings (Fixed Time)



#### Options summary:

Wake system with Fixed Time	Disabled	Optimal Default, Failsafe Default
	Enabled	
En/Disable System wake on alarm event. When enabled, System will wake on the hr:min:sec specified		
Wake up day	0-31	Default 0
Select 0 for daily system wake up, 1-31 for witch day of the moth that you would like the system to wake up.		
Wake up day	0-23	Default 0
Select 0-23 For example enter 3 for 3am and 15 for 3pm		
Wake up day	0-59	Default 0
Select 0-59		
Wake up day	0-59	Default 0
Select 0-59		

## S5 RTC Wake Settings (Dynamic Time)



### Options summary:

Wake system with	Disabled	Optimal Default, Failsafe Default
Dynamic Time	Enabled	
En/Disable System wake on alarm event. When enabled, System will wake on current time + Increases minute(s)		
Wake up day	1-5	Default 1
Select 1-5		

## LAN Bypass Configuration

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.

Advanced

LAN Bypass Controller	[Enabled]	Configure LAN Bypass Function
LAN Bypass Status LED Configuratio	[LED OFF]	
LAN Bypass Kit 1 Configuration		↔: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
Mode for Power-on State	[PassTru]	
Mode for Power-off State	[PassTru]	
LAN Bypass Kit 2 Configuration		
Mode for Power-on State	[PassTru]	
Mode for Power-off State	[PassTru]	
MDT Configuration	[System Reset]	

Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.

## Options summary:

LAN Bypass Controller	Disabled	
	Enabled	Optimal Default, Failsafe Default
Configure LAN Bypass Function		
LAN Bypass Status LED Configuration	LED OFF	Optimal Default, Failsafe Default
	RED LED ON	
	RED LED BLINK	
	RED LED FAST BLINK	
	GREEN LED ON	
	GREEN LED BLINK	
Configure LAN Bypass Status LED.		
Mode for Power-on State	ByPass	Optimal Default, Failsafe Default
	PassTru	
Configure LAN kit behavior when system in power-on state. (Bypass/Pass Through)		
Mode for Power-off State	ByPass	Optimal Default, Failsafe Default
	PassTru	
Configure LAN kit behavior when system in power-off state. (Bypass/Pass Through)		
Mode for WDT triggering	ByPass	Optimal Default, Failsafe Default
	PassTru	
Configure LAN kit behavior when WDT is triggered. (Bypass/Pass Through)		
WDT Configuration	Force ByPass	Optimal Default, Failsafe Default
	System Reset	
Configure WDT behavior , \nSystem Reset\nForce Bypass		

## Serial Port Console Redirection



### Options summary:

Console Redirection	Disabled	
	Enabled	Optimal Default, Failsafe Default
Console Redirection Enable or Disable		

Aprio Setup Utility - Copyright (C) 2012 American Megatrends, Inc.

Advanced


<p>COM0</p> <p>Console Redirection Settings</p>		<p>Emulation: ANSI: Extended ASCII char set. VT100: ASCII char set. VT100+: Extends VT100 to support color, function keys, etc. VT-UTF8: Uses UTF8 encoding to map Unicode chars onto 1 or more bytes.</p>
Terminal Type	[VT100+]	
Bits per second	[115200]	<p>←→: Select Screen                  ↑↓: Select Item                  Enter: Select                  +/-: Change Opt.                  F1: General Help                  F2: Previous Values                  F3: Optimized Defaults                  F4: Save &amp; Exit                  ESC: Exit</p>
Data Bits	[8]	
Parity	[None]	
Stop Bits	[1]	
Flow Control	[None]	

Version 2.15.1236. Copyright (C) 2012 American Megatrends, Inc.

Options summary:

Terminal Type	VT100	Optimal Default, Failsafe Default
	VT100+	
	VT-UTF8	
	ANSI	
Emulation: ANSI, VT100, VT100+, VT-UTF8		
Bit per second	9600	Optimal Default, Failsafe Default
	19200	
	38400	
	57600	
	115200	
Selects serial port transmission speed		
Data Bits	7	Optimal Default, Failsafe Default
	8	
Data Bits		
Parity	None	Optimal Default, Failsafe Default
	Even	
	Odd	
	Mark	
	Space	
A parity bit can be sent with the data bits to detect some transmission errors.		
Stop Bits	1	Optimal Default, Failsafe Default
	2	
Stop bits indicate the end of a serial data packet.		
Flow Control	None	Optimal Default, Failsafe Default
	Hardware RTS/CTS	
Flow control can prevent data loss from buffer overflow.		

## Setup submenu: Chipset



## Processor Configuration

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.

Chipset

Processor Configuration	
Processor ID	000406D8
Processor Frequency	1.743GHz
Microcode Revision	00000118
L1 Cache RAM	112KB
L2 Cache RAM	1024KB
Processor Version	
Intel(R) Atom(TM) CPU C2358 @ 1.74GHz	

←+: Select Screen  
↑↓: Select Item  
Enter: Select  
+/-: Change Opt.  
F1: General Help  
F2: Previous Values  
F3: Optimized Defaults  
F4: Save & Exit  
ESC: Exit

Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.

## SATA Configuration

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.		
Chipset		
Sata controller	[Enabled]	Enables/Disables sata controller if supported by current cpu SKU.
Sata mode	[IDE]	
HDD Compatibility Mode	[Disabled]	
SATA Port 1	[Not Installed]	
CF Slot	[Not Installed]	
SATA Port 2	[Not Installed]	
SATA Port 3	[Not Installed]	
SATA Port 4	[Not Installed]	
SATA Port 5	[Not Installed]	
		→: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
Version 2.16.1242, Copyright (C) 2013 American Megatrends, Inc.		

## Options summary:

Sata controller	Enabled	Optimal Default, Failsafe Default
	Disabled	
Enables/Disables SATA controller if supported by current CPU SKU.		
SATA Mode	AHCI	Optimal Default, Failsafe Default
	IDE	
Select IDE / AHCI Mode		
HDD Compatibility Mode	Enabled	Optimal Default, Failsafe Default
	Disabled	
HDD Compatibility Mode		

## North Bridge Chipset Configuration

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.

Chipset

North Bridge Chipset Configuration

---


Memory Information

MRC Version	0.100.0.0
Total Memory	8192 MB
Memory Frequency	DDR3 - 1333 MHz

⬆⬆: Select Screen  
⬆⬆: Select Item  
Enter: Select  
+/-: Change Opt.  
F1: General Help  
F2: Previous Values  
F3: Optimized Defaults  
F4: Save & Exit  
ESD: Exit

Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.

## South Bridge Chipset Configuration




### Options summary:

IQAT	Enabled	Optimal Default, Failsafe Default
	Disabled	
Hides IQAT device from an OS		
USB Support	Enabled	Optimal Default, Failsafe Default
	Disabled	
USB Support Parameters		
Power Failure	Last state	Optimal Default, Failsafe Default
	Power On	
	Power Off	
Determine which state system should move to when restoring from AC power loss		




### Setup submenu: Boot




### Options summary:

Setup Prompt Timeout	1	Default
	1-65536	
Number of seconds to wait for setup activation key. 65535(0xFFFF) means indefinite waiting.		
Bootup NumLock State	On	Default
	Off	
Select the keyboard NumLock state		
Quiet Boot	Disabled	Default
	Enabled	
En/Disable showing boot logo.		
Boot from LAN PXE	Disabled	Default
	Enabled	
En/Disable boot from on board LAN		
Option ROM Messages	Force BIOS	Default
	Keep Current	
Set display mode for Option ROM		

## BBS Priorities



## Setup submenu: Save &amp; Exit



Chapter

4

**Driver  
Installation**

The FWS-2350 comes with an AutoRun CD-ROM that contains all drivers and utilities that can help you to install the driver automatically.

Insert the driver CD, the driver DVD-title will auto start and show the installation guide. If not, please follow the sequence below to install the drivers.

***Follow the sequence below to install the drivers:***

Step 1 – Install LAN Driver

Please read instructions below for further detailed installations.

## 4.1 Installation:

---

Insert the FWS-2350 CD-ROM into the DVD-ROM drive and install the drivers.

### Step 1 – Install LAN Driver

1. Move the base driver tar file to the directory of your choice. For example, use '/home/username/LAN' or '/usr/local/src/LAN'.
2. Untar/unzip the archive: `tar xzf <filename.tar.gz>`
3. Follow the instructions of section installation in the README
4. The README will help you install the driver step by step

Appendix

**A**

# Programming the Watchdog Timer

## A.1 Watchdog Timer Initial Program

Table 1 : SuperIO relative register table		
	Default Value	Note
Index	0x2E <sup>(Note1)</sup>	SIO MB PnP Mode Index Register 0x2E or 0x4E
Data	0x2F <sup>(Note2)</sup>	SIO MB PnP Mode Data Register 0x2F or 0x4F

Table 2 : Watchdog relative register table					
	LDN	Register	BitNum	Value	Note
Timer Counter	0x07 <sup>(Note3)</sup>	0x73 <sup>(Note4)</sup>		(Note24)	Time of watchdog timer (0~255) This register is byte access
Counting Unit	0x07 <sup>(Note5)</sup>	0x72 <sup>(Note6)</sup>	7 <sup>(Note7)</sup>	1 <sup>(Note8)</sup>	Select time unit. 1: second 0: minute
Watchdog Enable (KRST)	0x07 <sup>(Note9)</sup>	0x72 <sup>(Note10)</sup>	6 <sup>(Note11)</sup>	1 <sup>(Note12)</sup>	0: Disable 1: Enable
Timeout Status	0x07 <sup>(Note13)</sup>	0x71 <sup>(Note14)</sup>	0 <sup>(Note15)</sup>	1	1: Clear timeout status

```
*****
// SuperIO relative definition (Please reference to Table 1)
#define byte SIOIndex //This parameter is represented from Note1
#define byte SIOData //This parameter is represented from Note2
#define void IOWriteByte(byte IOPort, byte Value);
#define byte IOReadByte(byte IOPort);
// Watch Dog relative definition (Please reference to Table 2)
#define byte TimerLDN //This parameter is represented from Note3
#define byte TimerReg //This parameter is represented from Note4
#define byte TimerVal // This parameter is represented from Note24
#define byte UnitLDN //This parameter is represented from Note5
#define byte UnitReg //This parameter is represented from Note6
#define byte UnitBit //This parameter is represented from Note7
#define byte UnitVal //This parameter is represented from Note8
#define byte EnableLDN //This parameter is represented from Note9
#define byte EnableReg //This parameter is represented from Note10
#define byte EnableBit //This parameter is represented from Note11
#define byte EnableVal //This parameter is represented from Note12
#define byte StatusLDN // This parameter is represented from Note13
#define byte StatusReg // This parameter is represented from Note14
#define byte StatusBit // This parameter is represented from Note15
*****
```

```
*****
VOID Main(){
    // Procedure : AaeonWDTConfig
    // (byte)Timer : Time of WDT timer.(0x00~0xFF)
    // (boolean)Unit : Select time unit(0: second, 1: minute).
    AaeonWDTConfig();

    // Procedure : AaeonWDTEnable
    // This procedure will enable the WDT counting.
    AaeonWDTEnable();
}
*****
```

```
*****
// Procedure : AaeonWDTEnable
VOID AaeonWDTEnable (){
    WDTEnableDisable(EnableLDN, EnableReg, EnableBit, 1);
}

// Procedure : AaeonWDTConfig
VOID AaeonWDTConfig (){
    // Disable WDT counting
    WDTEnableDisable(EnableLDN, EnableReg, EnableBit, 0);
    // Clear Watchdog Timeout Status
    WDTClearTimeoutStatus();
    // WDT relative parameter setting
    WDTParameterSetting();
}

VOID WDTEnableDisable(byte LDN, byte Register, byte BitNum, byte Value){
    SIOBitSet(LDN, Register, BitNum, Value);
}

VOID WDTParameterSetting(){
    // Watchdog Timer counter setting
    SIOByteSet(TimerLDN, TimerReg, TimerVal);
    // WDT counting unit setting
    SIOBitSet(UnitLDN, UnitReg, UnitBit, UnitVal);
}

VOID WDTClearTimeoutStatus(){
    SIOBitSet(StatusLDN, StatusReg, StatusBit, 1);
}
*****
```

\*\*\*\*\*

```
VOID SIOEnterMBPnPMode(){
    Switch(SIOIndex){
        Case 0x2E:
            IOWriteByte(SIOIndex, 0x87);
            IOWriteByte(SIOIndex, 0x01);
            IOWriteByte(SIOIndex, 0x55);
            IOWriteByte(SIOIndex, 0x55);
            Break;
        Case 0x4E:
            IOWriteByte(SIOIndex, 0x87);
            IOWriteByte(SIOIndex, 0x01);
            IOWriteByte(SIOIndex, 0x55);
            IOWriteByte(SIOIndex, 0xAA);
            Break;
    }
}

VOID SIOExitMBPnPMode(){
    IOWriteByte(SIOIndex, 0x02);
    IOWriteByte(SIOData, 0x02);
}

VOID SIOSelectLDN(byte LDN){
    IOWriteByte(SIOIndex, 0x07); // SIO LDN Register Offset = 0x07
    IOWriteByte(SIOData, LDN);
}
```

\*\*\*\*\*

\*\*\*\*\*

VOID **SIOBitSet(byte LDN, byte Register, byte BitNum, byte Value){**

Byte TmpValue;

SIOEnterMBPnPMode();

SIOSelectLDN(byte LDN);

IOWriteByte(SIOIndex, Register);

TmpValue = IOReadByte(SIOData);

TmpValue &= ~(1 << BitNum);

TmpValue |= (Value << BitNum);

IOWriteByte(SIOData, TmpValue);

SIOExitMBPnPMode();

}

VOID **SIOByteSet(byte LDN, byte Register, byte Value){**

SIOEnterMBPnPMode();

SIOSelectLDN(LDN);

IOWriteByte(SIOIndex, Register);

IOWriteByte(SIOData, Value);

SIOExitMBPnPMode();

}

\*\*\*\*\*

Appendix

**B**

# I/O Information

## B.1 I/O Address Map

Input/output (I/O)	
[0000000000000000] - 000000000000CF7]	PCI bus
[000000000000020] - 000000000000021]	Programmable interrupt controller
[000000000000024] - 000000000000025]	Programmable interrupt controller
[000000000000028] - 000000000000029]	Programmable interrupt controller
[00000000000002C] - 00000000000002D]	Programmable interrupt controller
[00000000000002E] - 00000000000002F]	Motherboard resources
[000000000000030] - 000000000000031]	Programmable interrupt controller
[000000000000034] - 000000000000035]	Programmable interrupt controller
[000000000000038] - 000000000000039]	Programmable interrupt controller
[00000000000003C] - 00000000000003D]	Programmable interrupt controller
[000000000000040] - 000000000000043]	System timer
[00000000000004E] - 00000000000004F]	Motherboard resources
[000000000000050] - 000000000000053]	System timer
[000000000000060] - 000000000000060]	Standard PS/2 Keyboard
[000000000000061] - 000000000000061]	Motherboard resources
[000000000000063] - 000000000000063]	Motherboard resources
[000000000000064] - 000000000000064]	Standard PS/2 Keyboard
[000000000000065] - 000000000000065]	Motherboard resources
[000000000000067] - 000000000000067]	Motherboard resources
[000000000000070] - 000000000000070]	Motherboard resources
[000000000000070] - 000000000000077]	System CMOS/real time clock
[000000000000080] - 000000000000080]	Motherboard resources
[000000000000092] - 000000000000092]	Motherboard resources
[0000000000000A0] - 0000000000000A1]	Programmable interrupt controller
[0000000000000A4] - 0000000000000A5]	Programmable interrupt controller
[0000000000000A8] - 0000000000000A9]	Programmable interrupt controller
[0000000000000AC] - 0000000000000AD]	Programmable interrupt controller
[0000000000000B0] - 0000000000000B1]	Programmable interrupt controller
[0000000000000B2] - 0000000000000B3]	Motherboard resources
[0000000000000B4] - 0000000000000B5]	Programmable interrupt controller
[0000000000000B8] - 0000000000000B9]	Programmable interrupt controller
[0000000000000BC] - 0000000000000BD]	Programmable interrupt controller
[000000000000170] - 000000000000177]	ATA Channel 1
[0000000000001F0] - 0000000000001F7]	ATA Channel 0
[000000000000376] - 000000000000376]	ATA Channel 1
[000000000000378] - 00000000000037F]	Printer Port (LPT1)
[0000000000003B0] - 0000000000003BB]	Intel(R) Atom(TM) processor C2000 product family PCIe Root Port 4 - 1F13
[0000000000003B0] - 0000000000003BB]	Silicon Motion SM718/SM750
[0000000000003C0] - 0000000000003DF]	Intel(R) Atom(TM) processor C2000 product family PCIe Root Port 4 - 1F13
[0000000000003C0] - 0000000000003DF]	Silicon Motion SM718/SM750
[0000000000003F6] - 0000000000003F6]	ATA Channel 0

[00000000000000B0 - 00000000000000B1]	Programmable interrupt controller
[00000000000000B2 - 00000000000000B3]	Motherboard resources
[00000000000000B4 - 00000000000000B5]	Programmable interrupt controller
[00000000000000B8 - 00000000000000B9]	Programmable interrupt controller
[00000000000000BC - 00000000000000BD]	Programmable interrupt controller
[0000000000000170 - 0000000000000177]	ATA Channel 1
[00000000000001F0 - 00000000000001F7]	ATA Channel 0
[0000000000000376 - 0000000000000376]	ATA Channel 1
[0000000000000378 - 000000000000037F]	Printer Port (LPT1)
[00000000000003B0 - 00000000000003BB]	Intel(R) Atom(TM) processor C2000 product family PCIe Root Port 4 - 1F13
[00000000000003B0 - 00000000000003BB]	Silicon Motion SM718/SM750
[00000000000003C0 - 00000000000003DF]	Intel(R) Atom(TM) processor C2000 product family PCIe Root Port 4 - 1F13
[00000000000003C0 - 00000000000003DF]	Silicon Motion SM718/SM750
[00000000000003F6 - 00000000000003F6]	ATA Channel 0
[00000000000003F8 - 00000000000003FF]	Communications Port (COM1)
[0000000000000400 - 000000000000047F]	Motherboard resources
[00000000000004D0 - 00000000000004D1]	Programmable interrupt controller
[0000000000000500 - 00000000000005FE]	Motherboard resources
[0000000000000680 - 000000000000069F]	Motherboard resources
[0000000000000778 - 000000000000077F]	Printer Port (LPT1)
[0000000000000A00 - 0000000000000A2F]	Motherboard resources
[0000000000000A30 - 0000000000000A3F]	Motherboard resources
[0000000000000A40 - 0000000000000A4F]	Motherboard resources
[0000000000000D00 - 000000000000FFFF]	PCI bus
[000000000000A000 - 000000000000AFFF]	PCI Express standard Downstream Switch Port
[000000000000A000 - 000000000000BFFF]	Intel(R) Atom(TM) processor C2000 product family PCIe Root Port 3 - 1F12
[000000000000A000 - 000000000000BFFF]	PCI Express standard Upstream Switch Port
[000000000000B000 - 000000000000BFFF]	PCI Express standard Downstream Switch Port
[000000000000C000 - 000000000000CFFF]	Intel(R) Atom(TM) processor C2000 product family PCIe Root Port 1 - 1F11
[000000000000D000 - 000000000000DFFF]	Intel(R) Atom(TM) processor C2000 product family PCIe Root Port 1 - 1F10
[000000000000E000 - 000000000000E01F]	Intel(R) Atom(TM) processor C2000 product family PCU SMBus - 1F3C
[000000000000E0A0 - 000000000000E0AF]	Intel(R) Atom(TM) processor C2000 product family 2-Port IDE SATA 3 Controller - 1F30
[000000000000E0B0 - 000000000000E0BF]	Intel(R) Atom(TM) processor C2000 product family 2-Port IDE SATA 3 Controller - 1F30
[000000000000E100 - 000000000000E10F]	Intel(R) Atom(TM) processor C2000 product family 4-Port IDE SATA 2 Controller - 1F20
[000000000000E110 - 000000000000E11F]	Intel(R) Atom(TM) processor C2000 product family 4-Port IDE SATA 2 Controller - 1F20
[000000000000E120 - 000000000000E123]	Intel(R) Atom(TM) processor C2000 product family 4-Port IDE SATA 2 Controller - 1F20
[000000000000E130 - 000000000000E137]	Intel(R) Atom(TM) processor C2000 product family 4-Port IDE SATA 2 Controller - 1F20
[000000000000E140 - 000000000000E143]	Intel(R) Atom(TM) processor C2000 product family 4-Port IDE SATA 2 Controller - 1F20
[000000000000E150 - 000000000000E157]	Intel(R) Atom(TM) processor C2000 product family 4-Port IDE SATA 2 Controller - 1F20
> - Interrupt request (IRQ)	
> - Large Memory	
> - Memory	

## B.2 Memory Address Map

Address Range	Device
[0000000000A0000 - 0000000000BFFFF]	Intel(R) Atom(TM) processor C2000 product family PCIe Root Port 4 - 1F13
[0000000000A0000 - 0000000000BFFFF]	PCI bus
[0000000000A0000 - 0000000000BFFFF]	Silicon Motion SM718/SM750
[0000000000C0000 - 0000000000DFFFF]	Motherboard resources
[0000000000E0000 - 0000000000FFFFFF]	Motherboard resources
[000000007FC00000 - 000000007FFFFFFF]	System board
[0000000080000000 - 00000000DFFFFFFF]	PCI bus
[00000000D8000000 - 00000000DBFFFFFF]	Intel(R) Atom(TM) processor C2000 product family PCIe Root Port 4 - 1F13
[00000000D8000000 - 00000000DBFFFFFF]	Silicon Motion SM718/SM750
[00000000D8000000 - 00000000DBFFFFFF]	Silicon Motion SM718/SM750
[00000000DF600000 - 00000000DF7FFFFF]	Intel(R) Atom(TM) processor C2000 product family PCIe Root Port 4 - 1F13
[00000000DF600000 - 00000000DF8FFFFF]	Intel(R) Atom(TM) processor C2000 product family PCIe Root Port 4 - 1F13
[00000000DF900000 - 00000000DF91FFFF]	Intel(R) I211 Gigabit Network Connection #3
[00000000DF900000 - 00000000DF9FFFFF]	PCI Express standard Downstream Switch Port
[00000000DF900000 - 00000000DFAFFFFFFF]	PCI Express standard Upstream Switch Port
[00000000DF900000 - 00000000DFAFFFFFFF]	Intel(R) Atom(TM) processor C2000 product family PCIe Root Port 3 - 1F12
[00000000DF920000 - 00000000DF923FFF]	Intel(R) I211 Gigabit Network Connection #3
[00000000DFA00000 - 00000000DFA1FFFF]	Intel(R) I211 Gigabit Network Connection #2
[00000000DFA00000 - 00000000DFAFFFFFFF]	PCI Express standard Downstream Switch Port
[00000000DFA20000 - 00000000DFA23FFF]	Intel(R) I211 Gigabit Network Connection #2
[00000000DFB00000 - 00000000DFB03FFF]	PCI Express standard Upstream Switch Port
[00000000DFC00000 - 00000000DFC1FFFF]	Intel(R) I211 Gigabit Network Connection
[00000000DFC00000 - 00000000DFCFFFFFFF]	Intel(R) Atom(TM) processor C2000 product family PCIe Root Port 2 - 1F11
[00000000DFC20000 - 00000000DFC23FFF]	Intel(R) I211 Gigabit Network Connection
[00000000DFD00000 - 00000000DFD1FFFF]	Intel(R) I211 Gigabit Network Connection #4
[00000000DFD00000 - 00000000DFDFFFFFFF]	Intel(R) Atom(TM) processor C2000 product family PCIe Root Port 1 - 1F10
[00000000DFD20000 - 00000000DFD23FFF]	Intel(R) I211 Gigabit Network Connection #4
[00000000DFE00000 - 00000000DFE1FFFF]	Intel(R) Ethernet Connection I354 #4
[00000000DFE20000 - 00000000DFE3FFFF]	Intel(R) Ethernet Connection I354 #3
[00000000DFE40000 - 00000000DFE5FFFF]	Intel(R) Ethernet Connection I354 #2
[00000000DFE60000 - 00000000DFE7FFFF]	Intel(R) Ethernet Connection I354
[00000000DFE80000 - 00000000DFE9FFFF]	Intel(R) Atom(TM) processor C2000 product family nCPM - 1F18
[00000000DFEA0000 - 00000000DFEBFFFF]	Intel(R) Atom(TM) processor C2000 product family PCIe Root Port 4 - 1F13
[00000000DFEC0000 - 00000000DFEDFFFF]	Intel(R) Atom(TM) processor C2000 product family PCIe Root Port 3 - 1F12
[00000000DFEE0000 - 00000000DFEFFFFFFF]	Intel(R) Atom(TM) processor C2000 product family PCIe Root Port 2 - 1F11
[00000000DFE00000 - 00000000DFE1FFFF]	Intel(R) Atom(TM) processor C2000 product family PCIe Root Port 1 - 1F10
[00000000DFE20000 - 00000000DFE23FFF]	Intel(R) Ethernet Connection I354 #4
[00000000DFE24000 - 00000000DFE27FFF]	Intel(R) Ethernet Connection I354 #3
[00000000DFE28000 - 00000000DFE2BFFF]	Intel(R) Ethernet Connection I354 #2
[00000000DFE2C000 - 00000000DFE2FFFF]	Intel(R) Ethernet Connection I354
[00000000DFE30000 - 00000000DFE33FFF]	Intel(R) Atom(TM) processor C2000 product family nCPM - 1F18
[00000000DFE34000 - 00000000DFE3401F]	Intel(R) Atom(TM) processor C2000 product family PCU SMBus - 1F3C

[0000000080000000 - 00000000DFFFFFFF]	PCI bus
[00000000D8000000 - 00000000DBFFFFFF]	Intel(R) Atom(TM) processor C2000 product family PCIe Root Port 4 - 1F13
[00000000D8000000 - 00000000DBFFFFFF]	Silicon Motion SM718/SM750
[00000000DF600000 - 00000000DF7FFFFFFF]	Silicon Motion SM718/SM750
[00000000DF600000 - 00000000DF8FFFFFFF]	Intel(R) Atom(TM) processor C2000 product family PCIe Root Port 4 - 1F13
[00000000DF900000 - 00000000DF91FFFF]	Intel(R) I211 Gigabit Network Connection #3
[00000000DF900000 - 00000000DF9FFFFFFF]	PCI Express standard Downstream Switch Port
[00000000DF900000 - 00000000DFAFFFFFFF]	PCI Express standard Upstream Switch Port
[00000000DF900000 - 00000000DFBFFFFFFF]	Intel(R) Atom(TM) processor C2000 product family PCIe Root Port 3 - 1F12
[00000000DF920000 - 00000000DFA23FFF]	Intel(R) I211 Gigabit Network Connection #3
[00000000DFA00000 - 00000000DFA1FFFF]	Intel(R) I211 Gigabit Network Connection #2
[00000000DFA00000 - 00000000DFAFFFFFFF]	PCI Express standard Downstream Switch Port
[00000000DFA20000 - 00000000DFA23FFF]	Intel(R) I211 Gigabit Network Connection #2
[00000000DFB00000 - 00000000DFB03FFF]	PCI Express standard Upstream Switch Port
[00000000DFC00000 - 00000000DFC1FFFF]	Intel(R) I211 Gigabit Network Connection
[00000000DFC00000 - 00000000DFCFFFFFFF]	Intel(R) Atom(TM) processor C2000 product family PCIe Root Port 2 - 1F11
[00000000DFC20000 - 00000000DFC23FFF]	Intel(R) I211 Gigabit Network Connection
[00000000DFD00000 - 00000000DFD1FFFF]	Intel(R) I211 Gigabit Network Connection #4
[00000000DFD00000 - 00000000DFDFFFFFFF]	Intel(R) Atom(TM) processor C2000 product family PCIe Root Port 1 - 1F10
[00000000DFD20000 - 00000000DFD23FFF]	Intel(R) I211 Gigabit Network Connection #4
[00000000DFE00000 - 00000000DFE1FFFF]	Intel(R) Ethernet Connection I354 #4
[00000000DFE20000 - 00000000DFE3FFFF]	Intel(R) Ethernet Connection I354 #3
[00000000DFE40000 - 00000000DFE5FFFF]	Intel(R) Ethernet Connection I354 #2
[00000000DFE60000 - 00000000DFE7FFFF]	Intel(R) Ethernet Connection I354
[00000000DFE80000 - 00000000DFE9FFFF]	Intel(R) Atom(TM) processor C2000 product family nCPM - 1F18
[00000000DFEA0000 - 00000000DFEBFFFF]	Intel(R) Atom(TM) processor C2000 product family PCIe Root Port 4 - 1F13
[00000000DFEC0000 - 00000000DFEDFFFF]	Intel(R) Atom(TM) processor C2000 product family PCIe Root Port 3 - 1F12
[00000000DFEE0000 - 00000000DFEFFFFFFF]	Intel(R) Atom(TM) processor C2000 product family PCIe Root Port 2 - 1F11
[00000000DFF00000 - 00000000DFF1FFFF]	Intel(R) Atom(TM) processor C2000 product family PCIe Root Port 1 - 1F10
[00000000DFF20000 - 00000000DFF23FFF]	Intel(R) Ethernet Connection I354 #4
[00000000DFF24000 - 00000000DFF27FFF]	Intel(R) Ethernet Connection I354 #3
[00000000DFF28000 - 00000000DFF2BFFF]	Intel(R) Ethernet Connection I354 #2
[00000000DFF2C000 - 00000000DFF2FFFF]	Intel(R) Ethernet Connection I354
[00000000DFF30000 - 00000000DFF33FFF]	Intel(R) Atom(TM) processor C2000 product family nCPM - 1F18
[00000000DFF34000 - 00000000DFF3401F]	Intel(R) Atom(TM) processor C2000 product family PCU SMBUS - 1F3C
[00000000DFF35000 - 00000000DFF353FF]	Intel(R) Atom(TM) processor C2000 product family USB Enhanced Host Controller - 1F2C
[00000000DFF36000 - 00000000DFF363FF]	Intel(R) Atom(TM) processor C2000 product family SMBUS 2.0 - 1F15
[00000000E0000000 - 00000000FFFFFFF]	System board
[00000000FEC00000 - 00000000FEC00FFF]	Advanced programmable interrupt controller
[00000000FED00000 - 00000000FEDFFFFFFF]	Motherboard resources
[00000000FEE00000 - 00000000FEEFFFFFFF]	Motherboard resources
[00000000FFA00000 - 00000000FFFFFFFF]	Motherboard resources

## B.3 IRQ Mapping Chart

Interrupt request (IRQ)	Description
(ISA) 0x00000000 (00)	System timer
(ISA) 0x00000001 (01)	Standard PS/2 Keyboard
(ISA) 0x00000004 (04)	Communications Port (COM1)
(ISA) 0x00000008 (08)	System CMOS/real time clock
(ISA) 0x0000000C (12)	Microsoft PS/2 Mouse
(ISA) 0x0000000E (14)	ATA Channel 0
(ISA) 0x0000000F (15)	ATA Channel 1
(ISA) 0x00000051 (81)	Microsoft ACPI-Compliant System
(ISA) 0x00000052 (82)	Microsoft ACPI-Compliant System
(ISA) 0x00000053 (83)	Microsoft ACPI-Compliant System
(ISA) 0x00000054 (84)	Microsoft ACPI-Compliant System
(ISA) 0x00000055 (85)	Microsoft ACPI-Compliant System
(ISA) 0x00000056 (86)	Microsoft ACPI-Compliant System
(ISA) 0x00000057 (87)	Microsoft ACPI-Compliant System
(ISA) 0x00000058 (88)	Microsoft ACPI-Compliant System
(ISA) 0x00000059 (89)	Microsoft ACPI-Compliant System
(ISA) 0x0000005A (90)	Microsoft ACPI-Compliant System
(ISA) 0x0000005B (91)	Microsoft ACPI-Compliant System
(ISA) 0x0000005C (92)	Microsoft ACPI-Compliant System
(ISA) 0x0000005D (93)	Microsoft ACPI-Compliant System
(ISA) 0x0000005E (94)	Microsoft ACPI-Compliant System
(ISA) 0x0000005F (95)	Microsoft ACPI-Compliant System
(ISA) 0x00000060 (96)	Microsoft ACPI-Compliant System
(ISA) 0x00000061 (97)	Microsoft ACPI-Compliant System
(ISA) 0x00000062 (98)	Microsoft ACPI-Compliant System
(ISA) 0x00000063 (99)	Microsoft ACPI-Compliant System
(ISA) 0x00000064 (100)	Microsoft ACPI-Compliant System
(ISA) 0x00000065 (101)	Microsoft ACPI-Compliant System
(ISA) 0x00000066 (102)	Microsoft ACPI-Compliant System
(ISA) 0x00000067 (103)	Microsoft ACPI-Compliant System
(ISA) 0x00000068 (104)	Microsoft ACPI-Compliant System
(ISA) 0x00000069 (105)	Microsoft ACPI-Compliant System
(ISA) 0x0000006A (106)	Microsoft ACPI-Compliant System
(ISA) 0x0000006B (107)	Microsoft ACPI-Compliant System
(ISA) 0x0000006C (108)	Microsoft ACPI-Compliant System
(ISA) 0x0000006D (109)	Microsoft ACPI-Compliant System
(ISA) 0x0000006E (110)	Microsoft ACPI-Compliant System
(ISA) 0x0000006F (111)	Microsoft ACPI-Compliant System
(ISA) 0x00000070 (112)	Microsoft ACPI-Compliant System
(ISA) 0x00000071 (113)	Microsoft ACPI-Compliant System
(ISA) 0x00000072 (114)	Microsoft ACPI-Compliant System

 (ISA) 0x00000072 (114)	Microsoft ACPI-Compliant System
 (ISA) 0x00000073 (115)	Microsoft ACPI-Compliant System
 (ISA) 0x00000074 (116)	Microsoft ACPI-Compliant System
 (ISA) 0x00000075 (117)	Microsoft ACPI-Compliant System
 (ISA) 0x00000076 (118)	Microsoft ACPI-Compliant System
 (ISA) 0x00000077 (119)	Microsoft ACPI-Compliant System
 (ISA) 0x00000078 (120)	Microsoft ACPI-Compliant System
 (ISA) 0x00000079 (121)	Microsoft ACPI-Compliant System
 (ISA) 0x0000007A (122)	Microsoft ACPI-Compliant System
 (ISA) 0x0000007B (123)	Microsoft ACPI-Compliant System
 (ISA) 0x0000007C (124)	Microsoft ACPI-Compliant System
 (ISA) 0x0000007D (125)	Microsoft ACPI-Compliant System
 (ISA) 0x0000007E (126)	Microsoft ACPI-Compliant System
 (ISA) 0x0000007F (127)	Microsoft ACPI-Compliant System
 (ISA) 0x00000080 (128)	Microsoft ACPI-Compliant System
 (ISA) 0x00000081 (129)	Microsoft ACPI-Compliant System
 (ISA) 0x00000082 (130)	Microsoft ACPI-Compliant System
 (ISA) 0x00000083 (131)	Microsoft ACPI-Compliant System
 (ISA) 0x00000084 (132)	Microsoft ACPI-Compliant System
 (ISA) 0x00000085 (133)	Microsoft ACPI-Compliant System
 (ISA) 0x00000086 (134)	Microsoft ACPI-Compliant System
 (ISA) 0x00000087 (135)	Microsoft ACPI-Compliant System
 (ISA) 0x00000088 (136)	Microsoft ACPI-Compliant System
 (ISA) 0x00000089 (137)	Microsoft ACPI-Compliant System
 (ISA) 0x0000008A (138)	Microsoft ACPI-Compliant System
 (ISA) 0x0000008B (139)	Microsoft ACPI-Compliant System
 (ISA) 0x0000008C (140)	Microsoft ACPI-Compliant System
 (ISA) 0x0000008D (141)	Microsoft ACPI-Compliant System
 (ISA) 0x0000008E (142)	Microsoft ACPI-Compliant System
 (ISA) 0x0000008F (143)	Microsoft ACPI-Compliant System
 (ISA) 0x00000090 (144)	Microsoft ACPI-Compliant System
 (ISA) 0x00000091 (145)	Microsoft ACPI-Compliant System
 (ISA) 0x00000092 (146)	Microsoft ACPI-Compliant System
 (ISA) 0x00000093 (147)	Microsoft ACPI-Compliant System
 (ISA) 0x00000094 (148)	Microsoft ACPI-Compliant System
 (ISA) 0x00000095 (149)	Microsoft ACPI-Compliant System
 (ISA) 0x00000096 (150)	Microsoft ACPI-Compliant System
 (ISA) 0x00000097 (151)	Microsoft ACPI-Compliant System
 (ISA) 0x00000098 (152)	Microsoft ACPI-Compliant System
 (ISA) 0x00000099 (153)	Microsoft ACPI-Compliant System
 (ISA) 0x0000009A (154)	Microsoft ACPI-Compliant System
 (ISA) 0x0000009B (155)	Microsoft ACPI-Compliant System

 (ISA) 0x0000009B (155)	Microsoft ACPI-Compliant System
 (ISA) 0x0000009C (156)	Microsoft ACPI-Compliant System
 (ISA) 0x0000009D (157)	Microsoft ACPI-Compliant System
 (ISA) 0x0000009E (158)	Microsoft ACPI-Compliant System
 (ISA) 0x0000009F (159)	Microsoft ACPI-Compliant System
 (ISA) 0x000000A0 (160)	Microsoft ACPI-Compliant System
 (ISA) 0x000000A1 (161)	Microsoft ACPI-Compliant System
 (ISA) 0x000000A2 (162)	Microsoft ACPI-Compliant System
 (ISA) 0x000000A3 (163)	Microsoft ACPI-Compliant System
 (ISA) 0x000000A4 (164)	Microsoft ACPI-Compliant System
 (ISA) 0x000000A5 (165)	Microsoft ACPI-Compliant System
 (ISA) 0x000000A6 (166)	Microsoft ACPI-Compliant System
 (ISA) 0x000000A7 (167)	Microsoft ACPI-Compliant System
 (ISA) 0x000000A8 (168)	Microsoft ACPI-Compliant System
 (ISA) 0x000000A9 (169)	Microsoft ACPI-Compliant System
 (ISA) 0x000000AA (170)	Microsoft ACPI-Compliant System
 (ISA) 0x000000AB (171)	Microsoft ACPI-Compliant System
 (ISA) 0x000000AC (172)	Microsoft ACPI-Compliant System
 (ISA) 0x000000AD (173)	Microsoft ACPI-Compliant System
 (ISA) 0x000000AE (174)	Microsoft ACPI-Compliant System
 (ISA) 0x000000AF (175)	Microsoft ACPI-Compliant System
 (ISA) 0x000000B0 (176)	Microsoft ACPI-Compliant System
 (ISA) 0x000000B1 (177)	Microsoft ACPI-Compliant System
 (ISA) 0x000000B2 (178)	Microsoft ACPI-Compliant System
 (ISA) 0x000000B3 (179)	Microsoft ACPI-Compliant System
 (ISA) 0x000000B4 (180)	Microsoft ACPI-Compliant System
 (ISA) 0x000000B5 (181)	Microsoft ACPI-Compliant System
 (ISA) 0x000000B6 (182)	Microsoft ACPI-Compliant System
 (ISA) 0x000000B7 (183)	Microsoft ACPI-Compliant System
 (ISA) 0x000000B8 (184)	Microsoft ACPI-Compliant System
 (ISA) 0x000000B9 (185)	Microsoft ACPI-Compliant System
 (ISA) 0x000000BA (186)	Microsoft ACPI-Compliant System
 (ISA) 0x000000BB (187)	Microsoft ACPI-Compliant System
 (ISA) 0x000000BC (188)	Microsoft ACPI-Compliant System
 (ISA) 0x000000BD (189)	Microsoft ACPI-Compliant System
 (ISA) 0x000000BE (190)	Microsoft ACPI-Compliant System
 (PCD) 0x00000003 (03)	Intel(R) Atom(TM) processor C2000 product family PCU SMBus - 1F3C
 (PCD) 0x0000000B (11)	Intel(R) Atom(TM) processor C2000 product family nCPM - 1F18
 (PCD) 0x0000000B (11)	Intel(R) Atom(TM) processor C2000 product family SMBus 2.0 - 1F15
 (PCD) 0x00000010 (16)	Intel(R) Atom(TM) processor C2000 product family RCEC - 1F16
 (PCD) 0x00000011 (17)	Intel(R) Atom(TM) processor C2000 product family USB Enhanced Host Controller - 1F2C
 (PCD) 0x00000012 (18)	Intel(R) Atom(TM) processor C2000 product family 4-Port IDE SATA 2 Controller - 1F20

	(PCI) 0x00000012 (18)	Intel(R) Atom(TM) processor C2000 product family 4-Port IDE SATA 2 Controller - 1F20
	(PCI) 0x00000012 (18)	PCI Express standard Upstream Switch Port
	(PCI) 0x00000013 (19)	Silicon Motion SM718/SM750
	(PCI) 0xFFFFFCC1 (-63)	Intel(R) I211 Gigabit Network Connection #3
	(PCI) 0xFFFFFCC2 (-62)	Intel(R) I211 Gigabit Network Connection #3
	(PCI) 0xFFFFFCC3 (-61)	Intel(R) I211 Gigabit Network Connection #3
	(PCI) 0xFFFFFCC4 (-60)	Intel(R) I211 Gigabit Network Connection #3
	(PCI) 0xFFFFFCC5 (-59)	Intel(R) I211 Gigabit Network Connection #2
	(PCI) 0xFFFFFCC6 (-58)	Intel(R) I211 Gigabit Network Connection #2
	(PCI) 0xFFFFFCC7 (-57)	Intel(R) I211 Gigabit Network Connection #2
	(PCI) 0xFFFFFCC8 (-56)	Intel(R) I211 Gigabit Network Connection #2
	(PCI) 0xFFFFFCC9 (-55)	Intel(R) I211 Gigabit Network Connection
	(PCI) 0xFFFFFCCA (-54)	Intel(R) I211 Gigabit Network Connection
	(PCI) 0xFFFFFCCB (-53)	Intel(R) I211 Gigabit Network Connection
	(PCI) 0xFFFFFCC4 (-52)	Intel(R) I211 Gigabit Network Connection
	(PCI) 0xFFFFFCCD (-51)	Intel(R) I211 Gigabit Network Connection #4
	(PCI) 0xFFFFFCE (-50)	Intel(R) I211 Gigabit Network Connection #4
	(PCI) 0xFFFFFCCF (-49)	Intel(R) I211 Gigabit Network Connection #4
	(PCI) 0xFFFFFCD0 (-48)	Intel(R) I211 Gigabit Network Connection #4
	(PCI) 0xFFFFFDD1 (-47)	Intel(R) Ethernet Connection I354
	(PCI) 0xFFFFFDD2 (-46)	Intel(R) Ethernet Connection I354
	(PCI) 0xFFFFFDD3 (-45)	Intel(R) Ethernet Connection I354
	(PCI) 0xFFFFFDD4 (-44)	Intel(R) Ethernet Connection I354
	(PCI) 0xFFFFFDD5 (-43)	Intel(R) Ethernet Connection I354
	(PCI) 0xFFFFFDD6 (-42)	Intel(R) Ethernet Connection I354
	(PCI) 0xFFFFFDD7 (-41)	Intel(R) Ethernet Connection I354
	(PCI) 0xFFFFFDD8 (-40)	Intel(R) Ethernet Connection I354
	(PCI) 0xFFFFFDD9 (-39)	Intel(R) Ethernet Connection I354
	(PCI) 0xFFFFFDDA (-38)	Intel(R) Ethernet Connection I354
	(PCI) 0xFFFFFDDB (-37)	Intel(R) Ethernet Connection I354 #2
	(PCI) 0xFFFFFDDC (-36)	Intel(R) Ethernet Connection I354 #2
	(PCI) 0xFFFFFDD4 (-35)	Intel(R) Ethernet Connection I354 #2
	(PCI) 0xFFFFFDE (-34)	Intel(R) Ethernet Connection I354 #2
	(PCI) 0xFFFFFDDF (-33)	Intel(R) Ethernet Connection I354 #2
	(PCI) 0xFFFFFDE0 (-32)	Intel(R) Ethernet Connection I354 #2
	(PCI) 0xFFFFFDE1 (-31)	Intel(R) Ethernet Connection I354 #2
	(PCI) 0xFFFFFDE2 (-30)	Intel(R) Ethernet Connection I354 #2
	(PCI) 0xFFFFFDE3 (-29)	Intel(R) Ethernet Connection I354 #2
	(PCI) 0xFFFFFDE4 (-28)	Intel(R) Ethernet Connection I354 #2
	(PCI) 0xFFFFFDE5 (-27)	Intel(R) Ethernet Connection I354 #3
	(PCI) 0xFFFFFDE6 (-26)	Intel(R) Ethernet Connection I354 #3
	(PCI) 0xFFFFFDE7 (-25)	Intel(R) Ethernet Connection I354 #3

	(PCI) 0xFFFFFD7 (-41)	Intel(R) Ethernet Connection I354
	(PCI) 0xFFFFFD8 (-40)	Intel(R) Ethernet Connection I354
	(PCI) 0xFFFFFD9 (-39)	Intel(R) Ethernet Connection I354
	(PCI) 0xFFFFFDA (-38)	Intel(R) Ethernet Connection I354
	(PCI) 0xFFFFFDB (-37)	Intel(R) Ethernet Connection I354 #2
	(PCI) 0xFFFFFDC (-36)	Intel(R) Ethernet Connection I354 #2
	(PCI) 0xFFFFFDD (-35)	Intel(R) Ethernet Connection I354 #2
	(PCI) 0xFFFFFDE (-34)	Intel(R) Ethernet Connection I354 #2
	(PCI) 0xFFFFFDF (-33)	Intel(R) Ethernet Connection I354 #2
	(PCI) 0xFFFFFE0 (-32)	Intel(R) Ethernet Connection I354 #2
	(PCI) 0xFFFFFE1 (-31)	Intel(R) Ethernet Connection I354 #2
	(PCI) 0xFFFFFE2 (-30)	Intel(R) Ethernet Connection I354 #2
	(PCI) 0xFFFFFE3 (-29)	Intel(R) Ethernet Connection I354 #2
	(PCI) 0xFFFFFE4 (-28)	Intel(R) Ethernet Connection I354 #2
	(PCI) 0xFFFFFE5 (-27)	Intel(R) Ethernet Connection I354 #3
	(PCI) 0xFFFFFE6 (-26)	Intel(R) Ethernet Connection I354 #3
	(PCI) 0xFFFFFE7 (-25)	Intel(R) Ethernet Connection I354 #3
	(PCI) 0xFFFFFE8 (-24)	Intel(R) Ethernet Connection I354 #3
	(PCI) 0xFFFFFE9 (-23)	Intel(R) Ethernet Connection I354 #3
	(PCI) 0xFFFFFEA (-22)	Intel(R) Ethernet Connection I354 #3
	(PCI) 0xFFFFFEB (-21)	Intel(R) Ethernet Connection I354 #3
	(PCI) 0xFFFFFEC (-20)	Intel(R) Ethernet Connection I354 #3
	(PCI) 0xFFFFFED (-19)	Intel(R) Ethernet Connection I354 #3
	(PCI) 0xFFFFFEE (-18)	Intel(R) Ethernet Connection I354 #4
	(PCI) 0xFFFFFEF (-17)	Intel(R) Ethernet Connection I354 #4
	(PCI) 0xFFFFFF0 (-16)	Intel(R) Ethernet Connection I354 #4
	(PCI) 0xFFFFFF1 (-15)	Intel(R) Ethernet Connection I354 #4
	(PCI) 0xFFFFFF2 (-14)	Intel(R) Ethernet Connection I354 #4
	(PCI) 0xFFFFFF3 (-13)	Intel(R) Ethernet Connection I354 #4
	(PCI) 0xFFFFFF4 (-12)	Intel(R) Ethernet Connection I354 #4
	(PCI) 0xFFFFFF5 (-11)	Intel(R) Ethernet Connection I354 #4
	(PCI) 0xFFFFFF6 (-10)	Intel(R) Ethernet Connection I354 #4
	(PCI) 0xFFFFFF7 (-9)	Intel(R) Ethernet Connection I354 #4
	(PCI) 0xFFFFFF8 (-8)	Intel(R) Ethernet Connection I354 #4
	(PCI) 0xFFFFFF9 (-7)	PCI Express standard Downstream Switch Port
	(PCI) 0xFFFFFFA (-6)	PCI Express standard Downstream Switch Port
	(PCI) 0xFFFFFFB (-5)	Intel(R) Atom(TM) processor C2000 product family PCIe Root Port 4 - 1F13
	(PCI) 0xFFFFFFC (-4)	Intel(R) Atom(TM) processor C2000 product family PCIe Root Port 3 - 1F12
	(PCI) 0xFFFFFFD (-3)	Intel(R) Atom(TM) processor C2000 product family PCIe Root Port 2 - 1F11
	(PCI) 0xFFFFFFE (-2)	Intel(R) Atom(TM) processor C2000 product family PCIe Root Port 1 - 1F10
>	 Large Memory	
>	 Memory	

Appendix

C

# Standard LAN Bypass Platform Settings

## C.1 Status LED

---

FWS-2350 provides a LED indicator which can show any LED status controlled by the AAEMON SDK. Users are able to program the LED status to express different status.

## C.2 Status LED Configuration

---

**Table 1 : Truth Table of Status LED**

STA_LED2	STA_LED1	STA_LED0	LED States
0	0	0	LED Off
0	0	1	Red
0	1	0	Red Blinking (Slowly)
0	1	1	Red Blinking (Quickly)
1	0	0	Reserved
1	0	1	Green Blinking (Slowly)
1	1	0	Green Blinking (Quickly)
1	1	1	Green

**Table 2 : Status LED relative register mapping table**

CPLD Slave Address 0x90 (Note1)

	Attribute	Offset(SMBUS)	BitNum	Value
STA_LED2	R/W	0x00 (Note2)	2	(Table 1)
STA_LED1	R/W	0x00 (Note2)	1	(Table 1)
STA_LED0	R/W	0x00 (Note2)	0	(Table 1)

### C.3 Status LED Sample Code

---

```

*****
#define Byte    CPLD_SLAVE_ADDRESS //This parameter is represented from Note1
#define Byte    OFFSET             //This parameter is represented from Note2
*****

bData = aaeonSmbusReadByte(CPLD_SLAVE_ADDRESS, OFFSET);

switch( LED_FLAG)
{
case 0:
{
    //LED Off
    //BIT2=0, BIT1=0, BIT0=0
    bData = bData & 0xF8;
    break;
}
case 1:
{
    //Red LED On
    //BIT2=0, BIT1=0, BIT0=1
    bData = (bData & 0xF8) | 0x01;
    break;
}
case 2:
{
    //Red LED Blink
    //BIT2=0, BIT1=1, BIT0=0
    bData = (bData & 0xF8) | 0x02;
    break;
}
case 3:
{
    //Red LED Fast Blink
    //BIT2=0, BIT1=1, BIT0=1
    bData = (bData & 0xF8) | 0x03;
    break;
}
}

```

```
}
case 4:
{
    //Green LED On
    //BIT2=1, BIT1=1, BIT0=1
    bData = (bData & 0xF8) | 0x07;
    break;
}
case 5:
{
    //Green LED Blink
    //BIT2=1, BIT1=0, BIT0=1
    bData = (bData & 0xF8) | 0x05;
    break;
}
case 6:
{
    //Green LED Fast Blink
    //BIT2=1, BIT1=1, BIT0=0
    bData = (bData & 0xF8) | 0x06;
    break;
}
default:
    break;
}

SmbusWriteByte(CPLD_SLAVE_ADDRESS, 0x00, bData);
```

\*\*\*\*\*

## C.4 LAN Bypass

---

FWS-2350 provides LAN Bypass kit and allow uninterrupted network traffic even if a single in-line appliance is shut down or became unresponsive.

## C.5 LAN Bypass Configuration

---

**Table 1 : ID Select table of LAN kit**

LAN_ID2	LAN_ID1	LAN_ID0	LAN kit selected
0	0	0	LAN Kit 1 Selected
0	0	1	LAN Kit 2 Selected
0	1	0	LAN Kit 3 Selected
0	1	1	LAN Kit 4 Selected
1	0	0	LAN Kit 5 Selected
1	0	1	LAN Kit 6 Selected
1	1	0	LAN Kit 7 Selected
1	1	1	LAN Kit 8 Selected

**Table 2 : LAN Bypass relative register table**

Function	Description
LAN_ID3	Use for selecting which LAN kit will be configured, refer to Table 1 of ID Select table of LAN kit. They should be set before ACT_EN.
LAN_ID2	
LAN_ID1	
LAN_ID0	
PWR_ON	Use for configuring LAN Bypass function behavior to LAN kit, when system power on. 1: Bypass 0: Pass Through
PWR_OFF	Use for configuring LAN Bypass function behavior to LAN kit, when system power off. 1: Bypass 0: Pass Through

WDT_EN	Use for configuring WDT function behavior to LAN kit, when WDT triggered. 0: Normal WDT reset (Default) 1: Force Bypass
ACT_EN	Use for activating programming of LAN kit. It is edge triggering (falling edge 1 to 0) and should be set to high(1) as its normal state.

**Table 3 : LAN Bypass relative register mapping table**

CPLD Slave Address 0x90 (Note1)				
	Attribute	Offset(SMBUS)	BitNum	Value
LAN_ID3	R/W	0x01(Note2)	3	(Table 1)
LAN_ID2	R/W	0x01(Note2)	2	(Table 1)
LAN_ID1	R/W	0x01(Note2)	1	(Table 1)
LAN_ID0	R/W	0x01(Note2)	0	(Table 1)
PWR_ON	R/W	0x01(Note2)	6	(Table 2)
PWR_OFF	R/W	0x01(Note2)	5	(Table 2)
WDT_EN	R/W	0x01(Note2)	4	(Table 2)
ACT_EN	R/W	0x01(Note2)	7	(Table 2)

## C.6 LAN Bypass Sample Code

```

*****
#define Byte    CPLD_SLAVE_ADDRESS //This parameter is represented from Note1
#define Byte    OFFSET             //This parameter is represented from Note2
*****

// Select Lan Pair
BYTE bLanSel = LAN_PAIR;

BYTE bData = SmbusReadByte(CPLD_SLAVE_ADDRESS, OFFSET);
// Set Reg01h bit3
if(bLanSel & 0x08)
    bData = bData | 0x08;
else
    bData = bData & 0xF7;

```

```
// Set Reg01h bit2
if(bLanSel & 0x04)
    bData = bData | 0x04;
else
    bData = bData & 0xFB;
// Set Reg01h bit1
if(bLanSel & 0x02)
    bData = bData | 0x02;
else
    bData = bData & 0xFD;
// Set Reg01h bit0
if(bLanSel & 0x01)
    bData = bData | 0x01;
else
    bData = bData & 0xFE;

// Power On Action (Reg01h bit6)
if(SET_PASS_THROUGH) // Pass Through
    bData = bData & 0xBF;
else // Bypass
    bData = bData | 0x40;

// Power Off Action (Reg01h bit5)
if(SET_PASS_THROUGH) // Pass Through
    bData = bData & 0xDF;
else // Bypass
    bData = bData | 0x20;

// WDT Action (Reg01h bit4)
if(SET_WDT_RESET) // Reset
    bData = bData & 0xEF;
else // Bypass
    bData = bData | 0x10;

SmbusWriteByte(CPLD_SLAVE_ADDRESS, OFFSET, bData);

// Apply Settings (Reg01h bit7)
```

```
bData = SmbusReadByte(CPLD_SLAVE_ADDRESS, OFFSET);
SmbusWriteByte(CPLD_SLAVE_ADDRESS, OFFSET, bData & 0x7F);
Sleep(500);
bData = SmbusReadByte(CPLD_SLAVE_ADDRESS, OFFSET);
SmbusWriteByte(CPLD_SLAVE_ADDRESS, OFFSET, bData | 0x80);
```

\*\*\*\*\*

### C.7 Software Reset Button

FWS-2350 provides a general propose input button can be used to reset any settings in the AAeon SDK.

### C.8 Software Reset Button Configuration

**Table 2 : LAN Bypass relative register table**

Function	Description
BTN_STS	Reading this register returns the pin level status which is normal high active low. 0: Pin Level States Low. 1: Pin Level States High.

**Table 1 : Soft Reset Button register mapping table**

	Attribute	Register(I/O)	BitNum	Value
BTN_STS	R	0xA05(Note1)	4(Note2)	(Note3)

### C.9 Software Reset Button Sample Code

```
*****
#define Word    BTN_STS        //This parameter is represented from Note1
#define Byte    BTN_STS_R      //This parameter is represented from Note2
*****
Byte GET_Value (Word IoAddr, Byte BitNum,Byte Value){
    BYTE    TmpValue;
```

```
    TmpValue = inportb (IoAddr);
    return  (TmpValue & (1 << BitNum))
}
*****
VOID Main() {
    Byte RstBtn;

    RstBtn = GET_Value (BTN_STS, BTN_STS_R);    // Active Low
}
*****
```